

REPLACEMENT PARTS SECTION

Depending on what replacement parts you are ordering
the following information will be needed:

GRINDER COMPONENTS

Serial Number
Model Number of Grinder

ENGINE COMPONENTS

Brand
Engine Serial Number
Engine Spec. Number

NOTICE

When ordering any replacement parts you should have the serial number (S/N) and model of the machine to ensure that you receive the correct replacement part. See page 6 for typical serial number & work order number locations.

NOTICE


All nuts, bolts, washers, and many other components can be ordered by physical description.

NOTICE

Some of the components shown in this section are for optional equipment and may not apply to every machine.

NOTICE

Bandit Industries Inc. reserves the right to make changes in models, size, design, installations and applications on any part without notification.

MODEL 2250R FRAME COMPONENTS**NOTICE**

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

MODEL 2250R FRAME COMPONENTS


LOCATION	PART NUMBER	DESCRIPTION
1.	900-4914-00	1/2"-20NF Lug Nut
2 a.	203-2000-33	Wheel Lock Holder
b.	900-4916-32	Hub Lock Pin
3 a.	900-5909-22	18" x 8.50" - 10" Tire & White, 5 Bolt Rim (Specify Left or Right)
b.	900-5909-20	18" x 8.50" - 10" Tire Only
c.	900-5909-21	10" x 6" White, 5 Bolt Rim Only
4 a.	900-4909-08	1"-8NC Slotted Hex Nut
b.	900-4911-75	3/16" x 2" Cotter Pin
5.	203-3000-58	Free Wheel Hub Washer
6.	203-3000-57	Bearing Retainer
7.	900-1910-07	Retaining Ring
8.	900-1910-01	Bearing Seal
9.	900-1910-02	Wheel Bearing
10.	900-1910-03	Bearing Cup
11 a.	203-2000-23	Free Wheel Drive Hub Assembly (Includes 5-10)
b.	900-5905-97	1/2"-20NF Stud Only
12 a.	203-2000-22	Free Wheel Drive Lock
b.	203-3002-47	Key for Free Wheel Drive Lock
13.	900-1916-52	Drive Axle Bearing
14.	203-3000-41	Drive Axle
15.	203-2000-14	Chain Drive Cover
16 a.	900-1917-70	Drive Axle Sprocket - 24 Tooth
b.	203-3000-80	Key for Drive Axle Sprocket
17 a.	203-2000-18	Drive Axle Hub
b.	203-3002-46	Key for Drive Axle Hub
c.	900-5905-97	1/2"-20NF Stud Only
18.	900-4904-46	1" Mill Carb Washer
19 a.	900-4916-39	Drive Axle Chain - 65 Pitches Long
b.	900-1901-19	Master Link (Not Shown)
c.	900-1901-18	Half Link (Not Shown)
20.	203-2000-16	Drive Sprocket Cover
21.	900-1902-42	Split Bushing - 1-1/4" OD x 1" ID x 1"
22.	900-1917-89	Drive Motor Sprocket - 15 Tooth
23.	203-3000-94	Drive Motor Mount
24.	900-3952-49	Braking Drive Motor
25 a.	900-3953-06	Hydraulic Oil Cooler
b.	900-3965-78	Hydraulic Oil Cooler Fan Only
26.	206-2000-13	Hydraulic Oil Cooler Fan Cover Assembly
27 a.	900-9910-28	Manual Holder
b.	900-4916-30	Tether for Manual (Not Shown)
28.	900-2903-76	Machine Hour Meter
29.	900-7901-35	Battery Box
30.	900-6911-34	12 Volt Battery
31 a.	206-3000-91	Side Frame Chip Curtain (Start ??/??)
b.	206-3000-47	Side Frame Chip Curtain (Pre ??/??)
32 a.	206-3000-92	Side Frame Chip Curtain Strap (Start ??/??)
b.	206-3000-48	Side Frame Chip Curtain Strap (Pre ??/??)
33.	206-3000-39	Middle Frame Chip Curtain
34.	206-3000-40	Middle Frame Chip Curtain Strap
35 a.	900-3937-80	Engine Oil Drain Hose
b.	900-3936-41	Cap for Engine Oil Drain Hose

NOTICE

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

MODEL 2250R CUTTER WHEEL ARM COMPONENTS**NOTICE**

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

MODEL 2250R CUTTER WHEEL ARM COMPONENTS


LOCATION	PART NUMBER	DESCRIPTION
1.	206-2000-07	Chip Pan
2.	203-3002-97	Chip Curtain - 14" Wide
3.	203-3001-49	Chip Curtain Strap - 14"
4.	203-3002-98	Chip Curtain - 17" Wide
5.	203-3001-44	Chip Curtain Strap - 17"
6.	203-3002-71	Stub Shaft Brace
7.	203-3002-72	Backer Plate
8.	206-2000-06	Cutter Wheel Arm Assembly
9.	203-2000-21	Cutter Wheel Motor Guard Assembly
10.	206-3000-35	Cutter Wheel Lift Cylinder Bottom Pin
11.	900-1918-01	Split Bushing - 1-1/4" OD x 1" ID x 2"
12 a.	203-1000-10	Up / Down Main Pivot Pin Assembly (Includes 12-15)
b.	203-3000-46	Up / Down Main Pivot Pin Only
13.	900-4909-01	1" Mill Carb Washer
14.	900-4909-08	1"-8NC Slotted Hex Nut
15.	900-4911-75	3/16" x 2" Cotter Pin
16.	900-1902-42	Split Bushing - 1-1/4" OD x 1" ID x 1"
17.	206-2000-05	Swing Pivot Assembly
18.	206-3000-24	Cutter Wheel Lift Cylinder Top Pin
19.	900-4917-49	Cutter Wheel Lock Pin
20 a.	203-2000-10	Upper Pivot Pin Assembly (Includes 21)
b.	900-4911-84	Grease Zerk - 1/4"
21.	203-3000-79	Pivot Pin Retainer Washer
22 a.	203-2000-09	Lower Pivot Pin Assembly (Includes 21)
b.	900-4911-84	Grease Zerk - 1/4"
23.	900-3941-35	Cutter Wheel Lift Cylinder
24.	900-3958-80	Swing Cylinder
25.	900-3934-20	Cylinder Pin - 1" x 2-7/8"

NOTICE


Parts may not be exactly as shown.

NOTICE


Nuts, bolts, washers, and all other components can be ordered by physical description.

CUTTER WHEEL & TEETH COMPONENTS

NEW RIVER "REVOLUTION" CUTTER WHEEL & TEETH



BANDIT CUTTER WHEEL WITH GREEN TEETH

**NOTICE**

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

CUTTER WHEEL & TEETH COMPONENTS


LOCATION	PART NUMBER	DESCRIPTION
1.	900-4918-43	14mm x 55mm Hex Head Bolt
2. a.	900-3959-06	Cutter Wheel Motor
b.	900-3951-91	Manifold Block For Cutter Wheel Motor
3.	900-4907-88	14mm Hex Nut
4.	900-1919-18	Taper Lock Coupler
5. a.	203-3002-57	Cutter Wheel Hub - New Revolution Wheel
b.	203-3002-56	Cutter Wheel Hub - Green Teeth Wheel
6. a.	900-9912-85	New River "Revolution" Cutter Wheel - Hex Teeth (Incl. Teeth & Holders)
b.	203-3001-05	Bandit Cutter Wheel for Green Teeth
7.	900-4906-73	1/2"-13NC x 1-3/4" Hex Head Bolt
8.	203-2000-69	Stub Shaft Assembly
9.	900-4915-79	1/2"-13NC x 1" Flat Head Cap Screw
10.	900-9912-25	Holder With Locator Pin for Hex Teeth (8 Required)
11.	900-9912-26	Holder Without Locator Pin for Hex Teeth (8 Required)
12.	900-9909-99	Tooth Nut (24 Required)
13. a.	900-9912-22	Lead Tooth "Shorts" - Hex (8 Required)
b.	900-9912-22	Side Tooth "Longs" - Hex (16 Required)
14. a.	900-9907-76	Green Tooth With Nut
b.	900-9907-15	18 Green Teeth Kit (Incl. Pockets & Bolts)
15.	900-9907-14	Pocket Bolt
16.	900-9907-05	Straight Pocket
17.	900-9907-04	Angle Pocket
18.	900-9904-57	1/2" Allen Key Socket For 1/2" Drive (Not Shown)

NOTICE

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

MODEL 2250R STEERING COMPONENTS


LOCATION	PART NUMBER	DESCRIPTION
1 a.	206-2000-01	Pivot Steering Mount
b.	900-4911-84	Grease Zerk - 1/4"
2.	900-1902-50	Split Bushing - 1-1/4" OD x 1" ID x 1-1/2"
3.	900-4900-80	1"-8NC Nylon Insert Hex Lock Nut
4.	900-4913-38	1"-8NC x 5-1/2" Hex Head Bolt (1-1/4" of Thread) - Special
5.	900-1919-25	Split Bushing - 1-1/4" OD x 1" ID x 1/2"
6.	900-1912-57	Split Bushing - 1-1/2" OD x 1-1/4" ID x 1"
7.	206-2000-04	Steering Pivot Pin Assembly
8.	993-200022	Steering Cylinder Pin - 5-1/8" Long (Road) Side
9.	993-200023	Steering Cylinder Pin - 4" Long (Curb) Side
10.	900-4907-28	3/16" Lynch Pin
11.	900-3937-68	Steering Cylinder
12.	203-1000-03	Steering Tie Rod Assembly
13 a.	900-5909-22	18" x 8.50" - 10" Tire & White, 5 Bolt Rim (Specify Left or Right)
b.	900-5909-20	18" x 8.50" - 10" Tire Only
c.	900-5909-21	10" x 6" White, 5 Bolt Rim Only
14.	900-4914-00	1/2"-20NF Lug Nut
15.	206-2000-03	Steering Spindle Assembly - Right (Curb) Side
16.	206-2000-02	Steering Spindle Assembly - Left (Road) Side

NOTICE

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

CUTTER WHEEL ENGAGEMENT LEVER COMPONENTS

LOCATION	PART NUMBER	DESCRIPTION
**	206-1000-07	Complete Cutter Wheel Engagement Lever Assembly
1.	206-2000-11	Cutter Wheel Engagement Lever Mount Assembly
2.	900-4909-75	1/4"-20NC Cutter Wheel Engagement Lever Mount Bolt
3.	900-9906-75	Black Plastic Handle
4.	206-2000-12	Pump Engagement Handle Assembly
5.	900-4915-67	Spring w/ Loop Ends
6.	900-4900-13	3/8"-16NC Pump Engagement Handle Pivot Bolt
7.	900-4906-40	5/16"-18NC Pump Engagement Handle Mount Bolt
8.	206-3000-74	Pump to Engagement Handle Connection Block


NOTICE

Parts may not be exactly as shown.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

FUEL TANK COMPONENTS



LOCATION	PART NUMBER	DESCRIPTION
1 a.	206-1000-09	Fuel Tank Assembly (Start ???/???)
b.	206-1000-06	Fuel Tank Assembly (Pre ???/???)
c.	206-2000-19	Fuel Tank Weldment (Start ???/???)
d.	206-2000-09	Fuel Tank Weldment (Pre ???/???)
2 a.	900-2929-09	Rochester Sight Gauge for Fuel Tank - 8"
b.	900-2903-55	Face for Sight Gauge Only
3.	900-3943-22	1/4" NPTF To 3/16" Hose Barb
4.	900-3909-03	Suction Pipe Assembly
5. a.	900-3941-30	Fuel (Gasoline) Locking Fill Cap - Black
b.	900-4912-40	Padlock With Short Shackle for Tank With Locking Cap (Not Shown)
c.	P812	Key for Padlock (Not Shown)
6.	900-3922-60	Magnetic Drain Plug

NOTICE

Parts may not be exactly as shown.

NOTICE


Tank assemblies vary with options. Specify all options when ordering.

NOTICE

Components vary with fuel type. Specify gas or diesel when ordering fuel tank components.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

HYDRAULIC TANK COMPONENTS

LOCATION	PART NUMBER	DESCRIPTION
1.	988-300134	Clean Out Door - Hydraulic tank
2.	900-3950-33	Rubber O-Ring
3.	900-3944-78	Suction Screen
4.	900-3922-60	Magnetic Drain Plug
5.	900-3900-44	Glass Sight Gauge for Hydraulic Tank
6 a.	900-3941-30	Hydraulic Locking Fill Cap - Black
b.	900-4912-40	Padlock With Short Shackle for Tank With Locking Cap (Not Shown)
c.	P812	Key for Padlock (Not Shown)
7.	900-3951-31	In-Tank Return Filter Assembly - Includes Filter
8.	900-3951-32	In-Tank Hydraulic Oil Filter Only
9 a.	206-1000-08	Hydraulic Tank Assembly (Start ??/??)
b.	206-1000-05	Hydraulic Tank Assembly (Pre ??/??)
c.	206-2000-18	Hydraulic Tank Weldment (Start ??/??)
d.	206-2000-08	Hydraulic Tank Weldment (Pre ??/??)

NOTICE


Parts may not be exactly as shown.

NOTICE

Tank assemblies vary with options. Specify all options when ordering.

NOTICE

Nuts, bolts, washers, and all other components can be ordered by physical description.

MODEL 2250R HYDRAULIC COMPONENTS**NOTICE**

Parts may not be exactly as shown.

NOTICE

Make sure to order components according to fitting type, fittings may vary on all components.

Hydraulic components, fittings, hoses will vary depending on optional equipment.

Order by physical description.

MODEL 2250R HYDRAULIC COMPONENTS

LOCATION	PART NUMBER	DESCRIPTION
1 a.	900-3951-91	Cutter Wheel Motor Manifold Relief
b.	900-3956-04	Relief Only
2.	900-3959-06	Cutter Wheel Motor
3.	900-3958-80	Swing Cylinder
4.	900-3941-35	Cutter Wheel Lift Cylinder
5.	900-3944-78	Hydraulic Tank Strainer
6 a.	900-3951-32	In-Tank Hydraulic Oil Filter Only
b.	900-3951-31	In-Tank Return Filter Assembly - Includes Filter
7.	See Page 61	Hydraulic Tank
8.	900-3937-68	Steering Cylinder
9.	900-3953-06	Oil Cooler
10.	900-3963-72	Cutter Wheel Pump
11.	900-3965-15	Flow Control
12 a.	900-3943-52	Shuttle Valve Only
b.	900-3945-55	Shuttle Valve Block Only
13 a.	900-3952-74	Manual Control Valve - 4 Bank
b.	900-3952-76	Valve Handle Only (Not Shown)
14 a.	900-3956-84	Double Counter Balance
b.	900-3929-09	Counter Balance Relief Only
15.	900-3965-16	Cross Line Swing Relief
16.	900-3952-49	Braking Drive Motor

NOTICE

Parts may not be exactly as shown.

NOTICE

Make sure to order components according to fitting type, fittings may vary on all components.

Hydraulic components, fittings, hoses will vary depending on optional equipment.

Order by physical description.

MODEL 2250R HYDRAULIC COMPONENTS

1. 	2. 
In-Tank Return Filter Ass'y: 900-3951-31 In-Tank Hydraulic Oil Filter Only: 900-3931-52	Suction Screen: 900-3944-78
3. 	4. 
Double Counter Balance: 900-3956-84 Counter Balance Relief Only: 900-3929-09	Shuttle Valve Only: 900-3943-52 Shuttle Valve Block Only: 900-3943-55
5. 	6. 
Manual Control Valve - 4 Bank: 900-3952-74 Valve Handle Only: 900-3952-76	Cross Line Swing Relief: 900-3965-16

NOTICE

Parts may not be exactly as shown.

MODEL 2250R HYDRAULIC COMPONENTS

1.



Swing Cylinder: 900-3958-80

2.



Steering Cylinder: 900-3937-68

3.



Cutter Wheel Lift Cylinder: 900-3941-35

4.



Cutter Wheel Pump: 900-3963-72

NOTICE

Parts may not be exactly as shown.

MODEL 2250R HYDRAULIC COMPONENTS

1.  A large, rectangular hydraulic motor with two yellow caps on top and a long shaft extending from the bottom left.	2.  A rectangular metal manifold with several holes and a small protrusion at the bottom left.
Cutter Wheel Motor: 900-3959-06	Cutter Wheel Motor Manifold Relief: 900-3951-91 Relief Only: 900-3956-04
3.  A black, cylindrical hydraulic motor with a flange on the left side and a small cap on top.	4.  A metal valve assembly with a red handle and a small red cap on the bottom right.
Braking Drive Motor: 900-3952-49	Flow Control: 900-3965-15
5.  A blue oil cooler unit with a large black fan on the left side and various piping and fittings.	6.  A black cylindrical switch or sensor with two gold-colored terminals and a black cable.
Oil Cooler: 900-3953-06	Oil Cooler Temperature Switch: 900-3966-18

NOTICE

Parts may not be exactly as shown.

SERVICE RECORD

DATE	DESCRIPTION	AMOUNT

SERVICE RECORD

DATE	DESCRIPTION	AMOUNT